

BSH004

WELD ON 205 BEARING HOUSING

When inexpensive cast iron pillow blocks or flange bearings will not fit, or break from shock loads, these steel weld on housings may solve your problems. We developed these for material handling equipment that had limited space for mounting and mobile equipment where the cast iron housings broke.

The housing and the piece it is attaching to should be preheated 100°F to 200°F. Good fit and small skip welds will reduce warpage

We can quote making custom size and material weld on housings for any spherical O.D. wide inner ring bearing.

